

Charles Universal Broadband Enclosure

CUBE-PM64015xxx Series

General Description and Installation

1. GENERAL INTRODUCTION	1
1.1. Document Purpose	1
1.2. Product Purpose.....	1
1.3. Product Mounting and Location.....	1
2. PRODUCT DESCRIPTION.....	2
3. INSTALLATION	3
3.1. Inspecting the Product.....	3
3.2. Following and Using Safety Precautions.....	3
3.3. Obtaining Tools and Equipment.....	3
3.4. Preparing the Installation Site.....	3
3.5. Lifting the CUBE.....	4
3.6. Mounting the CUBE.....	4
3.7. CUBE Wiring and Equipment	6
3.8. Optional Puck Lock Kit	7
3.9. Conduit Seals.....	7
3.10. Verifying the Installation.....	7
4. PERIODIC MAINTENANCE.....	7
5. TECHNICAL ASSISTANCE AND REPAIR SERVICE.....	7
6. WARRANTY & CUSTOMER SERVICE	7
7. SPECIFICATIONS.....	8
7.1. Regulatory Specifications.....	8
7.2. Product Specifications.....	8
7.3. CUBE Models and Individual Specifications.....	8
7.4. Macro Alarm Panel Wiring	9




Figure 1 Front View of the CUBE

1. GENERAL INTRODUCTION

1.1. Document Purpose

This document provides general information for the CUBE-PM64015xxx family of the Charles Industries’ Universal Broadband Enclosure (CUBE) product line. Supplemental documentation that ships with the CUBE contains more detailed information about specific models. Figure 1 shows a closed front view of the enclosure.

-NOTE-

Hereafter, the Charles Universal Broadband Enclosure CUBE-PM64015xxx will be referred to as the “CUBE.”

1.2. Product Purpose

The CUBE consists of a protective enclosure for an integrated system of electronic components and equipment that can serve fiber and copper interfaces.

1.3. Product Mounting and Location

This enclosure is suitable for outside plant-type (OSP) locations and those that may require NEC compliance. The outdoor, weather-resistant CUBE is to be mounted on pad or steel grate. The installer connects the power, fiber and copper connections. Detailed mounting and installation information is covered in Section 3. Charles recommends the CPAD composite pad for pad mounting applications.

2. PRODUCT DESCRIPTION

The CUBE is a single compartment with 40RU of 23" horizontal rack rail spacing. A thermal unit is mounted on the door.

Figure 2 shows the CUBE dimensions.




Figure 2 CUBE Dimensions (in inches)

3. INSTALLATION

3.1. Inspecting the Product

The CUBE is shipped mounted upright on a skid. Remove the bolts, unpack the unit, and dispose of the packaging material.

-INSPECTION NOTE-

Visually inspect the unit for damages prior to installation. If the equipment was damaged in transit, immediately report the extent of the damage to the transportation company.

3.2. Following and Using Safety Precautions

Read the following site and safety tips, cautions, and warnings, then proceed with the paragraphs that follow.

- For installation, follow all National Electrical Codes (NEC) ANSI/NFPA 70, local, environmental, workplace, and company codes, safety procedures, and practices.
- Minimum spacing between the accessories and components and the housing for ITE equipment shall be maintained for safe operation of the equipment when installed in accordance with NEC ANSI/NFPA 70.
- Read all instructions, warnings and cautions on the equipment and in the documentation shipped with the product.
- Always connect ground connections first.
- Do not place this product on weak or unstable surfaces which may allow the product to fall, resulting in potentially serious damage(s) to persons or product.
- Only authorized trained personnel shall install the CUBE.
- In windy conditions, be sure to engage the door latches to secure the door in a stationary position.

3.3. Obtaining Tools and Equipment

Obtain the following recommended or needed items for installing the CUBE.

- Sufficient length and quantities of fiber cable (or pigtails)
- Cable scoring, opening, and cutting tools for cable sheathing, shields, wrappings, strength members and buffer tubes
- Wire strippers
- Crimpers
- Cable, tube, wire, and fiber cleaning materials
- Protective and/or insulated work gloves
- Safety glasses
- Tape measure
- Marking utensil
- #6 ground wire or rod and earth ground materials
- Bond strap (optional, from cable bond clamp to bond post)
- Any exterior cable strain relief, per company practice
- Slotted, hex, and Phillips screwdrivers
- Torque wrench
- Assorted cable ties, clips, or fasteners (optional)
- Can wrench (216 type tool)
- Derrick for lifting
- Level

3.4. Preparing the Installation Site

Observe the following site preparation recommendations.

- Leave adequate horizontal and vertical space between multiple installations to allow for proper cable access, as well as enough room around the enclosure to open the door(s).
- The site must meet minimal personnel and equipment safety requirements.
- The distance from the cable entry point should be consistent with local installation practices.
- The pad or platform must be able to support the weight of the CUBE.
- Run all fiber and copper facilities to the site.

3.5. Lifting the CUBE

See the supplemental documentation for CUBE weight. Charles recommends the following procedure for lifting the CUBE.

	WARNING	Prior to lifting, remove the lifting brackets that hold the mounting gasket in place. Set aside the gasket, and then replace the brackets. Failure to do so can result in a failure of the lifting bracket assembly.
--	----------------	---

3.5.1. Required Equipment

- One derrick (crane) capable of lifting the CUBE
- Spreader bars
- Four lifting slings or chains with each having a 2,500 lbs. capacity
- Connecting links to attach slings to the CUBE's lifting brackets
- 75-ft. long tagline rope

Insert the lifting sling connecting links securely through each of the lifting brackets as shown in Figure 3.

3.5.2. Warnings and Specific Safety Precautions

	WARNING	Improper hoisting equipment and unsafe lifting procedures can result in serious injury or death
--	----------------	--

Observe the following local safety procedures when performing the tasks in this section.

- Keep the CUBE away from any power lines.
- Keep bystanders away from the work operations at all times.
- Only trained operators shall operate the crane for lifting and setting the CUBE.
- Do not suspend loads over people or equipment.
- All persons working with hoisting equipment shall wear standard safety gear according to local practices including safety helmets and steel-toed shoes.
- Do not operate the hoisting equipment until all stabilizer are extended and in firm contact with the ground or adequate support structure.
- Do not attempt to retract or extend the stabilizers while a load is suspended.

3.6. Mounting the CUBE

The CUBE can be mounted on a new or existing concrete pad or steel grate platform. A loose gasket is provided for placing the CUBE on a concrete pad. If the gasket becomes damaged during installation, order a replacement under part number 80-005300-A. Ensure that the unit is level.

3.6.1. Torque Requirements

Torque all hardware as shown below (unless otherwise noted). These values apply to SAE Grade 1 & 2 Low Carbon Steel, ASTM A307 Low Carbon Steel, and Stainless Steel Grade 18-8.

Thread Size	In-lbs	Ft-lbs
4-40	4±10%	
6-32	8±10%	
8-32	16±10%	
10-32	26±10%	
12-24	50±10%	
1/4-20/M6	60±5%	5±5%
5/16-18	125±5%	10.4±5%
3/8-16	180±5%	15.0±5%
1/2-13	500±2%	41.7±2%
5/8-11	1000±1%	83.3±1%





Figure 3 Lifting the CUBE

3.6.2. Constructing a New Pad

- Use only concrete for new pad construction. Do not use substitute materials since they lack the rigidity for CUBE placement.
- Observe local building practices for pad construction. Charles recommends that the pad should extend a minimum of 8" beyond the CUBE base on all sides.
- Use a minimum of 6" of sand or gravel as a base for the pad for leveling purposes.
- Figure 4 shows the required conduit openings and mounting hole dimensions for entering/mounting the bottom of the CUBE. Use these dimensions when designing the pad.

	WARNING	<p>When pad mounting, the compression strength of the pad must be at least 4000 psi as determined by ASTM C39 test of compression strength of concrete cylinders.</p> <p>The slump of the concrete shall be 2" to 4" as determined by ASTM C143 test method.</p>
---	----------------	--




Figure 4
Mounting Hole Dimensions (in inches)
Viewed from Above

3.6.3. Mounting the CUBE on a Pad

Four customer supplied, corrosion resistant, 1/2"-13 hex head bolts with anchors are required for mounting the CUBE to the concrete pad. Use the following steps to mount the CUBE to a pad.

1. Layout, drill, and set the 1/2" anchors per manufacturer's recommendations. The embedment depth is not to exceed 3.5". Use the gasket as a mounting hole location template.
2. Clean any debris from the concrete pad.
3. Install the gasket by positioning it on the pad so that it is underneath the bottom of the CUBE when the cabinet is installed. Line up the gasket so that the cutouts are in proper position around the conduit opening and the bolt holes as shown in Figure 5.
4. Open the door to allow access to mounting holes.
5. Ensure that the CUBE is parallel to the pad surface as it is placed onto the pad and that it aligns with the holes in the pad and the gasket. Dress the cable/conduit so that it aligns with the CUBE openings as it is lowered onto the pad.
6. Place the CUBE on the pad. Loosen the slings so that all the weight is on the pad. Check that the CUBE is properly aligned.
7. Secure the CUBE to the pad using the 1/2"-13 hex head bolts. Tighten all bolts securely.
8. To secure the CUBE to a steel grate platform, install 1/2" corrosion-resistant Grade 5 steel hardware through the cabinet and platform grate. Ensure that the bolts are long enough to extend past the nut on the bottom side of the platform grate. For all mounting applications, each bolted joint should have a minimum Ø1 inch fender washer on the inside of the cabinet (and underside of the platform grate for platform mounting) with a lock washer. The washer on the underside of the platform must be large enough to cover both adjacent bearing bars as shown in Figure 6.
9. Once the CUBE is secured, remove the slings and tagline. Close the door.




Figure 5 **Gasket Installation**




Figure 6 **Installing on a Platform**

3.7. CUBE Wiring and Equipment

After the CUBE is properly mounted in the desired location, apply No-Ox where bus bar and other 2-hole lug connections will be made. Install ground and power connections. Always ground the equipment first, before making any other connections.

	WARNING	Perform all bonding and grounding connections prior to any electrical and communications connections.
--	----------------	--

In order to prevent condensation prior to being placed in service, do not remove the desiccant until the CUBE is sealed and power is applied. Basic electrical diagrams are shown in the supplemental documentation.

3.7.1. Ground Connection

Use the two 2x8 position ground bars provided in the equipment compartment for all grounding of internal equipment. Stack hardware as shown in Figure 7. External ground studs are available on the sides rear of CUBE for connecting a site ground wire.

3.7.2. Overheat Thermostat

The CUBE is equipped with an overheat (high temperature) alarm thermostat in the equipment compartment that provides a normally closed connection. The overheat alarm is factory set at 50°C in units with an HVAC system and 60°C in units with a heat exchanger. The alarm opens the connection if this temperature is exceeded.




Figure 7
Ground Bar Hardware Stack

-NOTE-

Changing the overheat (high-temp) thermostat default factory set points can lead to unnecessary alarms or system performance issues, such as equipment failures as a result of unreported alarms.

3.7.3. Macro Alarm Terminal Panel

An integrated macro-site alarm panel is mounted on the left wall of the cabinet. This panel provides forty protected dry contact alarm inputs to screw down terminals or 66-block connections (Figure 8).

The cabinet comes with a standard alarm schedule label (See Table 3). The table can be replaced or augmented to match the specific alarms being used. All connections are normally closed and open on alarm.




Figure 8 **Alarm Terminal Panel**

3.7.4. Fiber and Copper Entry

The CUBE has multiple Ø2.50" knockouts on the sides and bottom that accommodate Ø2.00" conduit fittings. See Figure 2 for knockout locations.

3.8. Optional Puck Lock Kit

Some CUBE models can be ordered with the optional puck lock kit (see Table 2 for available part numbers). If the kit is ordered, then the CUBE ships with locking kits installed at the factory. The front hinged door has one lock, while the removable rear panel has two locks. Figure 9 shows a CUBE with the puck locks installed.

3.9. Conduit Seals

All conduit openings on the CUBE must be completely sealed with a duct seal compound to prevent moisture from entering the CUBE. Use a moldable, flame-retardant putty style duct seal material. Do not use an expanding foam seal. Mold the putty so that the open space around the wire or conduit is completely sealed, as shown in Figure 10. If the openings must be accessed at any time, remove the putty and set it aside. When work is complete, re-mold the putty to re-seal the opening.

3.10. Verifying the Installation

Verify that earth ground and all grounding and bonding is complete and functional. After verifying that all installer connections are secure and complete, apply voltage.

4. PERIODIC MAINTENANCE

In the event that the enclosure must be opened in freezing conditions, use a narrow, pointed metallic object such as a screwdriver or chisel, along with a non-metallic device like a rubber mallet, to remove excessive ice buildup around the door and locking mechanism. A commercial aerosol de-icer spray can be used to free up locks and latches if needed. Use protective gloves and safety glasses when applying de-icer sprays.

Reset the GFCI duplex receptacle periodically to ensure it is working. The unit meets UL-943, which requires an auto-monitoring (self-testing) feature. A flashing or solid red LED indicates a fault. If the unit continues to show a fault after resetting, replace the unit.

The heat exchanger (if equipped) requires no scheduled maintenance other than cleaning the fans and heat exchanger core if they become contaminated with dust or residue. Remove the cover by removing the screws on the outside. Examine periodically to determine the required cleaning periods based on the installed environmental conditions.

Refer to the HVAC manual supplied with the HVAC (if equipped) for periodic maintenance requirements.

5. TECHNICAL ASSISTANCE AND REPAIR SERVICE

For questions on product repair or if technical assistance is required, contact Charles Technical Support.

847-806-8500

techserv@charlesindustries.com (email)

<http://www.charlesindustries.com/techserv.htm>

6. WARRANTY & CUSTOMER SERVICE

Charles Industries LLC offers a one-year warranty on the CUBE product. The Charles warranty is limited to the operation of the CUBE hardware as described in this documentation and does not cover equipment which may be integrated by a third party. The terms and conditions applicable to any specific sale of product shall be defined in the resulting sales contract. For questions on warranty or other customer service assistance, contact your Charles Customer Service Representative.

847-806-6300

mktserv@charlesindustries.com (email)

http://www.charlesindustries.com/main/telecom_sales_support.htm




Figure 9 Puck Locks




Figure 10 Applying Putty Seal

7. SPECIFICATIONS

7.1. Regulatory Specifications

- Designed to meet GR-487
- GFCI: UL-943 Listed

If CUBE's are field-modified, a customer provided ETL field evaluation of the modified components may be required to re-establish ETL certification to UL standards. Consult local jurisdictions for guidance on a site-by-site basis.

7.2. Product Specifications

Physical	
Dimensions	74"Hx32"Wx32"D
23" Equipment Rack Space and Hole Spacing	70" (40RU) rack spacing with tapped EIA #12-24 mounting holes
Materials	0.125" aluminum
Color	Off-white
Electrical	
Bonding and Grounding	(2) 2x8 position ground bars inside cabinet, external ground studs on sides and rear
Cable Entry	See Figure 2
Environmental	
Operating Temp. Range, Outside Enclosure	-40° to +115°F, -40° to 46°C
Operating Temp Range, Inside Enclosure	-40° to +149°F, -40° to 65°C
Humidity	0 to 95% (non-condensing)
Altitude	Up to 2,000 meters (6560 feet)
Kits and Replacement Parts	
Touch-up Paint	02-000290-0
216 Type Security Tool	07-002070-0
Replacement Gasket	80-005300-A
Shim Kit for Leveling	97-000010-0
Lift-Up Handle	39-000335-0
Door Rod Latch	39-000336-0
1/4 Turn Latch	39-000269-0
1/4 Turn Latch with Padlock Hasp	39-000311-0
4-Wire Door Alarm Switch (Black)	17-400319-0
HVAC Cutoff Switch (Black with White Button)	17-400322-0
15A GFCI Outlet	04-100207-0
Overheat Thermostat	99-004548-0

Table 1 CUBE Specifications

7.3. CUBE Models and Individual Specifications

Part Number	Thermal System	Puck Lock Kit Part Number (Optional)
CUBE-PM640157N1	10000BTU 48VDC HVAC system	96-SESPKLPMBLH
CUBE-PM640157NR	10000BTU 48VDC HVAC system	96-SESPKLPMBRH
CUBE-PM640158N1	12000BTU 48VDC HVAC system	96-SESPKLPMBLH
CUBE-PM64015PN1	3500W 48VDC Thermosiphon	96-SESPKLPMBLH

Table 2 CUBE Models and Individual Specifications

7.4. Macro Alarm Panel Wiring

Alarm Number	Description
CC1	Door Intrusion
CC2	Commercial Power Failure
CC3	Surge Suppressor/Lightening Arrestor
CC4	Rectifier Failure
CC5	Multiple Rectifier Failure
CC6	Battery Discharge
CC7	Low Voltage
CC8	DC Power Failure
CC9	Generator Running
CC10	Generator Low Fuel
CC11	Generator Failure
CC12	HVAC Failure
CC13	High Temp
CC14	Low Temp
CC15	Tower Light
CC16	Tower Light Side
CC17	RRH Up-Convertor Failure
CC18	RRH Power Failure
CC19	RRH High Humidity
CC20	RRH Intrusion
CC21	Smoke/Fire
CC22	Bus Bar Theft
CC23	Battery Breaker Alarm
CC24	
CC25	Microwave Critical
CC26	Microwave Major
CC27	Dehydrator Alarm
CC28	Fire Suppression Discharge
CC29	Fire Suppression Trouble
CC30	Secondary HVAC Running
CC31	Explosive Gas
CC32	High Humidity

Table 3 Macro Alarm Wiring Table