
BDO203-RG2S-W with Fiber Tap Supplemental Information

1. GENERAL INTRODUCTION

1.1. Document Purpose

This document provides supplemental information for routing fibers in the BDO203-RGyyy/W pedestal configurations with fiber module installed, where "yyy" indicates an optical fiber module type installed in the pedestal.

1.2. Fiber Routing

Route fibers as shown in Figure 1 (next page).

1. Fiber pigtailed from the Fiber Tap Module are attached to the CO side. Loop these once on the CO side and then route them through the slot on the left.
2. Pull the fiber pigtailed through to the drop side and connect these fibers to the SC/APC adapters.

2. TECHNICAL ASSISTANCE AND REPAIR SERVICE

For questions on product repair or if technical assistance is required, contact Charles Technical Support.

847-806-8500

techserv@charlesindustries.com (email)

<http://www.charlesindustries.com/techserv.htm>

3. WARRANTY & CUSTOMER SERVICE

Charles Industries, Ltd. offers a 5-year warranty on pedestals and a one-year warranty on fiber components. The Charles warranty is limited to the operation of the pedestal and fiber components hardware as described in this documentation and does not cover equipment which may be integrated by a third party. The terms and conditions applicable to any specific sale of product shall be defined in the resulting sales contract. For questions on warranty or other customer service assistance, contact your Charles Customer Service Representative.

847-806-6300

mktserv@charlesindustries.com (email)

http://www.charlesindustries.com/main/telecom_sales_support.htm




Figure 1 Fiber Routing